

Donning Poster Dräger PARAT® Soft Pack



1
Dräger PARAT Soft Pack



2
Break the security seal.



3
Pull the yellow flap downwards.



4
Open the Soft Pack **completely**. The front filter sealing plug should be automatically removed.



5
Remove the hood from the Soft Pack. Pull the hood against the hook and loop fastener holder, it will automatically open. The second filter sealing plug will automatically be detached when the hood is removed.



6
Widen the neck seal and pull the hood over your head. The inner head harness automatically adjusts to your head. Ensure that nose and chin sit comfortably in the half mask and that all hair is tucked into the hood.



7
Check the fit of the half mask by closing the front filtering opening with the palm of your hand. If negative pressure is not generated readjust the half mask to ensure a close fit over nose and mouth.



8
Ready for use.